

BXxxx: Large Boot Kits



Features:

- Large boots are used to weatherproof cable runs in conduit or pipe
- One-piece design; holes are molded into the boot jacket
- Kits include one boot jacket and two hose clamps
- Boots are cut from one edge to the interior hole(s), so can be opened and placed around the cable after completion of cable installation
- 6" and 8" boots are for use with conduit (fit 6" and 8" actual OD)
- 6-5/8" and 8-5/8" boots are for use with pipe; they fit 6" nominal (6-5/8" OD) and 8" nominal (8-5/8" OD) pipe sizes
- Blank boots have no holes and can be used to seal unused conduit or pipe or you can cut them for custom hole sizes or layouts

Construction:

- Boot jackets are molded from UV-resistant EPDM Rubber for long-term outdoor durability
- Hose clamps are stainless steel

Design Criteria:

- Can be used outdoors or indoors

BXxxx: Large Boot Kits

6" Boots

Part #	Cable Size & Type	Hole Size	# of Holes	U of M
BE784	7/8" Coax	1.110"	4	Each
BE1143	1-1/4" Coax	1.560"	3	Each
BE1582	1-5/8" Coax	2.000"	2	Each
BE1583	1-5/8" Coax	2.000"	3	Each
BEWR284	WR284 Rectangular Waveguide	3.00" x 1.50"	1	Each
BEZERO	Blank, No Holes	N/A	-	Each

6-5/8" Boots

Part #	Cable Size & Type	Hole Size	# of Holes	U of M
BF784	7/8" Coax	1.110"	4	Each
BF1143	1-1/4" Coax	1.560"	3	Each
BF1582	1-5/8" Coax	2.000"	2	Each
BF1583	1-5/8" Coax	2.000"	3	Each
BFZERO	Blank, No Holes	N/A	-	Each

8" Boots

Part #	Cable Size & Type	Hole Size	# of Holes	U of M
BC1583	1-5/8" Coax	2.000"	3	Each
BC1584	1-5/8" Coax	2.000"	4	Each

8-5/8" Boots

Part #	Cable Size & Type	Hole Size	# of Holes	U of M
BG784	7/8" Coax	1.110"	4	Each
BG1583	1-5/8" Coax	2.000"	3	Each
BG1584	1-5/8" Coax	2.000"	4	Each
BGZERO	Blank, No Holes	N/A	-	Each